


Mobile Vertical File

Assembly Instructions

for MODEL 614



Item	Description		QTY.
А		Upper T- Frame Has "2" holes for setting knobs	2
В		Lower T-Frame Has "3" holes for setting knobs	2
С		Upper U-Frame	2
D		Lower U-Frame Has holes for casters	2

Tools required for assembly: Phillips screwdriver

Item	Description		QTY.
Е		Setting Knob	10
F		Locking Caster	2
G		Caster	2
Н		End Cap	8
I		Wrench	1


Page 1 of 2 www.adircorp.com

Mobile Vertical File


Assembly Instructions

for MODEL 614


1. Slide lower U-Frames (part D) into Lower T-Frames (Part B) Making sure that holes for casters are facing down. Adjust to clamp size. Insert setting knobs (Part E) into sockets and tighten.




2. Insert casters (Parts F&G) into holes of lower U-Frames. Attach locking casters to same U-Frame.



3. Slide upper U-Frames (part C) into upper T-Frames (part A). Adjust to clamp size. Insert setting knobs (Part E) into sockets and tighten.



4. Slide Upper Frames into Lower Frames. Adjust to paper size. Insert setting knobs into holes and tighten.



Page 2 of 2 www.adircorp.com