

ASSEMBLY INSTRUCTIONS

9329 SINGLE ROLLING STAND

NOTE: Please count and inspect all pieces before disposing of any carton or packing materials.

When ordering components, specific color and/or size information may be required.
Contact a Mayline Customer Service Representative. 1-800-822-8037

COMPONENTS:


** Denotes Color Code

REF.#	QTY.	DESCRIPTION	PART No.
1	1	LOWER SPREADER	A1036**
2	2	SIDE FRAME ASSEMBLY	A3496**
3	1	SINGLE RACK ASSEMBLY	A3507**
4	1	FRAME EXTENSION ASSEMBLY	A3506**

HARDWARE BAG (PART No. A3591) *for individual item, order that part number

REF. #	QTY.	DESCRIPTION	PART No.
E1	2	END CAP	F368*
E2	2	Non-LOCKING CASTER	Q482*
E3	2	LOCKING CASTER	Q483*
E4	2	WASHER	W13*
E5	4	1/4-20 X 5/16 SET SCREW	X132*
E6	2	1/4-20 X 3" SCREW	X287*

1. Insert Frame Extension (4) into the tubes of the Side Frames (2).
2. Position with company logo on upper wall.
2. Slide posts of Single Rack Assembly (3) into the tubes of the Side Frames (2).
3. Install Casters in underside of frame. Position both Locking Casters (E3) at one end, preferably closest to the Lower Spreader (1).
4. Insert Plastic End Caps (E1) into the Single Rack Assembly (3). When Date File accessory 9391 is being added, End Plugs (E1) are inserted those tubes.
5. Insert Set Screws (E5) into Side Frames (2). Adjust to desired height (Maximum 60") and length (Maximum 42 1/2") by using set screws and wrench to lock in position.
6. Attach Lower Spreader (1) to Side Frames (2) using two 1/4-20 X 3" Screw (E6) and Washers (E4). Fully tighten Screws to secure Spreader in position.



I224 REV. 08 02-2016

(1)

